


**RAYBURN
200SFW/212SFW
COOKER**

***SPARE PARTS
MANUAL***

RAYBURN 200SFV/212SFV COOKER
TOP/BOTTOM OVEN DOORS, FIREDOOR & ASHPIT DOOR ASSEMBLIES

JULY 2009

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1		SCREW 5/16" BSW x 1 1/4 C/SNK HEAD	KCSK49900
2	R4829	FIREDOOR PROTECTION PLATE	RS5M22A
3		ROCKWOOL	
4	R1028	FIREDOOR HEAT SHIELD	JPAD37340
5		SCREW M5 x 25 LG HEX HD	KHEX50934
6	R4720	DOOR HINGE BUTTON - UP TO M06-051	RS4M301095
7	A2583	M6 x 6mm PATCHED PIN CUP PNT SKT GRUB	KGRB500437
8		HINGE PIN - UP TO M06-051	RS4M301104
8A	R2633	HINGE PIN - FROM M06-051	RO4M340227
9		WASHER NYLON 8 x 16 x 1mm	KWSR53500
10		FIREBOX DOOR - FROM NP05-027	RS5E300142
10A		FIREBOX DOOR - UP TO M05-144	RS5E300084
10B	R3594	FIREDOOR ASSY COMPLETE - UP TO M05-144	RS9M300084-212S
10C	R5291	FIREDOOR ASSY COMPLETE - POST M05-144	RS9M997167
11	R6481	CATCH PLATE - UP TO M05-144	RS4M301096P
12	R2061	DOOR HANDLE C/W SCREWS	RS9M31530COMP
13		ASHPIT DOOR	
13A	R3595	ASHPIT DOOR COMPLETE	RS9M300086-212S
14		SEE ITEM 16	
15		SEE ITEM 16	
16	R2084	SPIN V/V C/W FIXINGS	RS9M43460-COMP
17	R3417	M8 SELF LOCKING NUT	KNUT500327
18	R2636	DOOR HANDLE CATCH ASSY	RO9M340181COMP
19		INCLUDED IN ITEM 18	
20		SPRING DOOR CATCH (INCL. IN ITEM 18)	RO4M340297
21		WASHER M8 x 12 (INCL. IN ITEM 18)	KWSR53400
22		BRACKET DOOR STOP CATCH (INCL. IN ITEM 18)	RO4M340349
23	R2591	SIMMERING OVEN DOOR COMPLETE	RO9M340325COMP
24	R2759	BUSH - DOOR HINGE	RO4M340226
25	R2633	HINGE PIN	RO4M340227
26	R2641	SEAL - BOTTOM OVEN DOOR	JMAR340256
27	R2975	PAD INSULATION - SIMMERING OVEN DOOR	JPAD340466
28	R2974	BOTTOM OVEN DOOR LINING PANEL	RG2M313313
29		M6 x 25 LG C/SNK HEAD SCREW	KCSK500302
30	R3593	TOP OVEN DOOR COMPLETE	RO9M340138-355
31	R2432	THERMODIAL	RS4T301075
32	R1147	THERMODIAL SEALING RING	RG4M30412
33	R2642	SEAL TOP OVEN	JMAR340255
34	R2986	INSULATION PAD	JPAD340465
35	R2985	TOP OVEN DOOR LINING	RO2M313325
36	R2642	TAPE - DOOR	JMAR340255
37		GASKET - TOP OVEN DOOR	JGSG341290
38	R5290	BADGE - FROM NP05-26/27	RO4M343291




**RAYBURN 200SFW/212SFW COOKER
TOP/BOTTOM OVEN DOORS, FIREDOOR & ASHPIT DOOR
ASSEMBLIES**

**RAYBURN 200SFw/212SFw COOKer - UP TO M04-039
HOB PLATE, INSULATING COVERS & FLUE CHAMBER**

JUNE 2008

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1	R1640	BLANKING PLATE	RS4E38766
2		ROPE SEAL	
3		BLANKING PLATE STRAP	RS2M302054
4	R2244	FLUE SOCKET FIXING BRACKET	RS2M91190
5	R1612	FLUE SOCKET	RS4M42676
6		FLUE CHAMBER ASSY	RS2E91160
7		PIN 3/16" x 1" LG	KCTR37850
8	R1785	FLUE CHAMBER DOOR	RS5E-13344
9	R1788	DAMPER BLADE	RS5E3-16874
12	R1843	HOTPLATE PLUG	RS5M27-SP
13		HOTPLATE C/W PLUG	RS1M0-19779-27
14		ROPE T/SEAL No.4	
15	R1713	CORNER STAY BUTTON	RS4M24420
16	R1066	CORNER STAY NUT	KNUT53090
17	R2410	HOBPLATE	RG5E300040
18	A2314	HANDRAIL BRACKET	AG4M210853
19	A2975	HANDRAIL END CAP	AG4M210660
20	R1724	HANDRAIL	RG4M312141
21		ROPE SEAL	
22	R3689	SCREW M8 x 16	KHEX500026
23		COOKER MODEL BADGE	RS4M300097
24		GRUB SCREW M10 x 10	KGRB500165
24A	R2451	GRUB SCREW M10 x 16mm	KGRB500255
25		1/4" x 1 13/16 LG - SCREW C/SNK	KCSK50372
26	R1639	LINING COVER PLATE	RG2E310290
27	R1020	ROPE SEAL	JMAR20555
28		ROCKWOOL INSULATION	
29		INSULATING COVER ASSY	RG1M312012
30	R2349	PIVOT BRG	RS4M301041
31		BEARING PIN	
32	R3018	WASHER SEALING RING - HANDLE	JWSR53508
33	R1711	HANDLE BRACKET	RS4M23090
34	R2176	COIL HANDLE	RG4M310136



**RAYBURN 200SFW/212SFW COOKER - UP TO M04-039
HOB PLATE, INSULATING COVERS & FLUE CHAMBER**


**RAYBURN 200SF/212SF COOKER - FROM M04-039 NOVEMBER 2007
HOB PLATE, INSULATING COVERS & FLUE CHAMBER**

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1	R1640	BLANKING PLATE	RS4E38766
2		ROPE SEAL	
3		BLANKING PLATE FIXING STRAP	RS2M302054
4	R2244	FLUE SOCKET FIXING BRACKET	RS2M91190
5	R1612	FLUE SOCKET	RS4M42676
6		FLUE CHAMBER ASSEMBLY	RS1E300107
7	H1723	PIN 3/16" x 1"	KCTR37850
8	R1785	FLUE CHAMBER DOOR	RS5E3-13344
9	R5173	STOP BRACKET	RS2M300115
10	R5153	DAMPER BLADE	RS5E300113
11	R1843	HOTPLATE PLUG	RS5M27-SP
12		HOTPLATE C/W PLUG	RS1M0-19779-27
13		ROPE T/SEAL No. 4	
14	R1713	CORNER STAY BUTTON	RS4M24420
15	R1066	CORNER STAY NUT	KNUT53090
16	R4530	HOBPLATE	RS5E300105
17	A2314	HANDRAIL BRACKET	AG4M210853
18	A2975	HANDRAIL END CAP	AG4M210660
19	R1724	HANDRAIL	RG4M312141
20		ROPE SEAL	
21	R3689	SCREW M8 x 16	KHEX500026
22	R5024	COOKER MODEL BADGE - UP TO NP05-026/27	RS4M300097
23	R4722	TAPPING PLATE	RO2M342370
24	R4562	HINGE GASKET	JGSG342369
25	R4563	HINGE	RO4M342364
26	R4980	HINGE GASKET TOP	JGSG242404
27	R4564	HINGE COVER	RO2M342387
28		SCREW 1/4" x 1 13/16" RSD CSK CP	KRCK50372
29	R1614	LINING PANEL	RO2E340773
30	R3457	SEAL INSULATING LID	JMAR340790
31	R4565	INSULATING COVER BASE	RO5E342348
32	R5167	STRAP-LID CENTRE FIXING	RO2M342362
33	R2767	PAD COVER INSULATION	JPAD340307
34	R4566	INSULATING COVER	RO2M342347
35	R4863	COIL HANDLE CUP - SET OF 4	RO9M340521SET4
36	R3028	COIL HANDLE	RO4M340522
38	R4567	INSULATING COVER ASSEMBLY	RG1M313527

**RAYBURN 200SFW/212SFW COOKER
FRONT PLATE, BACK & SIDE PLATES, BASE PLATE**

JULY 2009

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1	R5049	BACK PLATE	RS2M302055
2	R1760	CORNER STAY RODS	RS4M44080
3	R2309	LOCKNUT 3/8" BSW	KNUT52911
4	R1631	SIDE PLATE - RH	RS2V90005
5	R1021	TOP HEAT SHIELD	JPAD30770
6		FRONT PLATE - FROM M05-144	RS5E300137
6A		FRONT PLATE - UP TO M05-144	RS5E300073
6B	R3670	FRONT PLATE C/W DOORS	RS9M-FP-212S
7	R2679	DOOR KEEP C/W WASHER	RO9M340185COMP
8	R2754	M8 FLANGE NUT	KNUT500260
9		SEE ITEM 7	
11	R5029	ASHPIT DOOR CATCH	RS4M300116
12		BASE PLATE	RG5M310096
13	R2828	BASE PLATE - FILLER PIECE	RG2M310097
14		ROPE SEAL	
15	R2216	ASHPIT DOOR FRAME	RS5M2-190
16	R2272	FIREBOX HEAT SHIELD	JPAD302017
17	R2938	LH SIDE PLATE	RS2V300071
18	R1622	SIDEPLATE COVER PLATE (212 SFW)- BLR	RS2V38991
18A	R6478	SIDEPLATE COVER PLATE (200 SFW)	RS2V39032
19	R2679	DOOR KEEP C/W WASHER	RO9M340185COMP
20	R5029	ASHPIT DOOR CATCH	RS4M300116




**RAYBURN 200SFW/212SFW COOKER
FRONT PLATE, BACK & SIDE PLATE, BASE PLATE**

**RAYBURN 200SFW/212SFW COOKER
BOILER, ASHPIT**

MARCH 2006


ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1	R5021	ALLTHREAD M12 x 40mm M5	KSTD50631
2	A2318	MUDLID BRIDGE PLATE	AS4M34780
3	R1774	MUDLID ONLY	RS5EMC2
4	R1720	GASKET - MUDLID	RS4M30410
5	R2070	FLOW & RETURN PIPE COLLARS (PAIR)	RS9M39PR
6		SCREW 3/16" BSW x 1/2" ROUNDHEAD	KRHD51499
7	R1983	BOILER 15" VE LINED C/W CONNECTOR RHO	RS9E89
8	R1824	RIDDLING BLOCK	RS5M148B-348B
9	R1748	RIDDLING ROD	RS4M41091
10	R1731	RIDDLING KNOB	RS4M34027
11	R1827	ASHPIT TOP PLATE	RS5M162B1
12	R1771	BOTTOMGRATE	RS5B146B1
12A	R2381	WOODGRATE	RS5B1-17752
13	R1820	BOTTOMGRATE FRAME	RS5M145B1
14	R1828	BOTTOMGRATE FRAME BRACKET RH	RS5M163B
15	R1829	BOTTOMGRATE FRAME BRACKET LH	RS5M164B
16	R1831	BOILER SUPPORT BASE PLATE	RS5M20
17	R1825	ASHPIT BACK PLATE	RS5M15
18	R1816	ASHPIT BOTTOM	RS5M14
19	R1596	ASHPAN	RS1M90040
20	R1623	RAKER	RS2V40573
21	R1900	ASHPAN LIFTING TOOL	RS5M61B
23	R1817	ASHPIT LH SIDE PLATE	RS5M143B
24	R1022	PAD - BARLAN	JPAD35398
25	R1818	F/B LH SIDE PLATE	RS5M144B



**RAYBURN 200SFW/212SFW COOKER
BOILER, ASHPIT**

**RAYBURN 200SFW/212SFW COOKER NOVEMBER 2007
HOB PROTRCTOR PLATE, TOP, & WARMING OVEN**

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1		ROPE	
2	R1806	HOB PROTECTOR PLATE	RS5M0-19753
3		ROPE	
4	R1868	OVEN TOP BACK FLUE PLATE	RS5M31B1
5	R1844	OVEN TOP RH FLUE PLATE	RS5M28B
6	R1845	OVEN TOP LH FLUE PLATE	RS5M29B
8	R5219	RH TOP OVEN VENT	RS5O103
9	R2672	FRONT FLUE FEATHER	RS5M300017
10	R1914	OVEN TOP PLATE	RS5O6B-RH
11		OVEN RH FIXED SIDE PLATE	RS507-RH
12	R4128	OVEN LH REMOVABLE SIDE PLATE	RG5M341249
13	R3853	OVEN BACK PLATE	RO5M342031
14	R2793	TOP OVEN SIDE FIXING BRACKET	RS2M93013
15		WASHER	
16	R1761	OVEN STAY ROD	RS4M44111
17	R2597	OVEN BOTTOM PLATE	RS5O300015
18	R2953	RH FIREBOX SIDE RETAINING BRACKET	RS5M301092
19	R2670	FIREBOX RH SIDE	RS5M300075
20	R2449	SUPPORT FOR WARMING OVEN	RS2M90115
21	R1822	RIDDLING BLOCK SUPPORT BRACKET	RS5M147B
22	R1906	ASHPIT RH SIDE PLATE	RS5O141B
23	R2690	BASE PLATE BRACKET	RG2M311231
23A		BASE PLATE BRACKET	RO2M323116
24	R2794	OVEN RETAINING BRACKET	RS2M301068
25	R4002	WARMING OVEN ASSEMBLY	RS1M301117
26	R2819	OVEN REFLECTOR DUCT ASSY	RG1M310012
27	R2701	WARMING OVEN VENT PIPE	RS2M91495
28	R4061	MEAT TIN	EMTY530219
29	R2571	GRILL RACK	RS4M311164
30	R2573	OVEN GRID SHELF	RS4M300070
31	R1618	OVEN SHELF	RO2M340757




**RAYBURN 200/SFW/212SFW COOKER
HOB PROTECTOR PLATE, TOP & WARMING PLATE**

**RAYBURN 200SFW/212SFW COOKER
INSULATION AND FIREBRICKS**

OCTOBER 2003

ITEM No.	CAT No.	DESCRIPTION	PRODUCT CODE
1 TO 4	R4505	INSULATION PACK (INCL ITEMS 1, 2, 3 & 4)	MRWF300091
5	R1661	TOP RH SIDE FIREBRICK	RS4F300002
6	R1659	BOTTOM RH SIDE FIREBRICK	RS4F300000
7	R1660	FIREBRICK - BOTTOM FRONT	RS4F300001
8	R1663	FIREBRICK - BOTTOM LH SIDE	RS4F300004
9	R1664	FIREBRICK - MID LH SIDE	RS4F300005
10	R1665	FIREBRICK - TOP LH SIDE	RS4F300007
11	R1666	FIREBRICK - TOP FRONT	RS4F300009
12	R1662	FIREBRICK - TOP BACK (NOT SHOWN)	RS4F300003



**RAYBURN 200SFW/212SFW COOKER
INSULATION & FIREBRICKS**